

# Apple® iPhone™ 3G



## Pocket Guide

## iPhone 3G Keyboard Layout


The SHIFT key.  
Double-tap for  
Caps Lock.

Press and hold on  
letters to reveal accent  
and format options.



Tap to reveal  
symbols, numbers,  
and punctuation.

In most cases, the new iPhone 3G keyboard can be used in both vertical and horizontal (landscape) mode. Many keyboard keys (e.g. vowels, the .com key) can be pressed and held to reveal variations, including accented versions, alternate punctuation, and symbols.

**To change the keyboard's default settings:** from the Home screen, open **Settings**  and choose **General** ▶ **Keyboard**. Make changes as needed.

**Note:** If you enable Caps Lock in the keyboard settings, you can double-tap the SHIFT key to toggle Caps Lock.

**Tip:** When typing uppercase letters, slide your finger from the SHIFT key to the desired letter to save a keystroke.